

NEW update	Brand	Type	Note	Plug and Play	Univerſal harness	Remark	Photo
	Alfa	147 <2002			190-500225W		
		147 2002>		190-5002110			2
		156 <2002			190-500225W		
		156 2002>		190-5002110			2
		156 Crosswagon		190-5002110			2
		159		190-5002130			3
		8C					
		Brera		190-5002130			3
NEW		Guilietta 2010>		190-5002130			2
		GT		190-5002110			2
		MiTo		190-5002130			3
		Spider 2007>		190-5002130			3
update	Audi	A1		190-5002230			
		A2		190-5002230			7
		A2 1.2TDI, 1.4TDI		190-5002310			7
		A3 <2005		190-5002230			7
		A3 TDI <2005		190-5002310			7
		A3 2005>		190-5002450			10
		A4 2001-2007		190-5002230			7
		A4 1.9&2.5 TDI 2001- 2007		190-5002310			7
		A4 2008>		190-5002450			2
		A5		190-5002450			
		A6 <2006		190-5002230			7
		A6 1.9&2.5 TDI <2006		190-5002310			7
		A6 2006>		190-5002450			10
		Q5		190-5002450			
		Q7		190-5002230			7
		Q7		190-5002230			7
		R8		190-5002450			
		TT		190-5002450			10
	BMW	1-series (E87) 2004>		190-5002470	190-500225W		18
		3-series (E90) 2005>		190-5002470	190-500225W		18
		5-series (E60-E61) 2003>		190-5002470	190-500225W		18
		6-series (E63-E64) 2004>		190-5002470	190-500225W		18
		7-series (E65) 2001>		190-5002470	190-500225W		18
	Cadillac	BLS		190-5002130			3
	Chevrolet	Aveo	Drive-by-wire models (E-gas) only	190-5002400			2
		Captiva 2.0 VCDI		190-5002390			20
		Captiva 2.4 4WD		190-5002390			20
		Colorado		190-5002480			
update		Epica VCDI		190-5002390			2
		HHR		190-5002130			3
		Lacetti		190-5002400			2
update		Nubira TCDI	Drive-by-wire models (E-gas) only	190-5002400			2
		Spark		190-5002390			
	Chrysler	PT Cruiser			190-500225W		19
		Sebring		190-5002360			6
		Voyager CRD 2006 - 2007			190-500034W		24
		Grand Voyager 2008>			190-500225W		25

NEW	Brand	Type	Note	Plug and Play	Univerſal harness	Remark	Photo
	Citroen	Berlingo <2006		190-500009A			8
		Berlingo 2006-2008		190-500017A			16
		Berlingo 2009>		190-500041A			16
		C1		190-5002220			11
		C2 <2006		190-500009A			1
update		C2 2006-2008		190-500017A			16
update		C2 2009>		190-500041A			
		C3 <2006		190-500009A			1
		C3 2006-2008		190-500017A			16
		C3 2009>		190-500041A			
		C4 <2008		190-500009A			1
		C4 Picasso <2008		190-500017A			16
		C4 2009>		190-500041A			
		C4 Picasso 2009>		190-500041A			
		C5 <2005		190-500009A			1
		C5 2005-2007		190-500017A			16
		C5 2008>		190-500017A			
		C5 (first generation)		190-500009A			8
		C8		190-500009A			8
		C-Crosser		190-5002360			6
	Jumper / Relay <2006		190-5002230			7	
	Jumper / Relay 2006>		190-5002110			2	
	Jumpy / Despatch <2008		190-500017A			16	
	Jumpy / Despatch 2009>		190-500041A				
	Nemo		190-5002110			2	
	Picasso 2006>		190-500017A			16	
	Xantia		190-500009A			8	
	Xsara		190-500009A			8	
	Xsara Picasso		190-500009A			8	
	Dacia	Duster Dci		190-5002140			7
		Logan Dci		190-5002140			7
		Sandero 1.2 16V		190-5002140			7
		Sandero Dci		190-5002140			7
	Dodge	Avenger		190-5002360			6
		Caliber		190-5002360			6
		Journey		190-5002360			6
		Nitro			190-500225W		25
		Ram Van CRD 2006-2007			190-500034W		24
	Ford	C-Max <2010		190-5002330			22
update		C-Max / Grand C-Max 2011>		190-5002160	190-500225W		25
		Fiesta 2002-2008		190-5002200			9
		Fiesta TDCI 2009> manual gearbox		190-5002330			22
		Fiesta 2009>		190-5002330			22
		Focus 2004 - 2007		190-5002330			22
		Focus 2008-2011		190-5002330			22
update		Focus USA 2008>		190-5002160	190-500225W		25
NEW		Focus 2011>		190-5002160	190-500225W		25
		Fusion		190-5002200			9
		Galaxy TDI <2006		190-5002310			7
		Galaxy 2006>		190-5002330			22
		Ka 2009-2010		190-5002380			20
		Ka 1.2 petrol Start/Stop 2011>	Euro-5	190-5002130			20
		Kuga		190-5002330			22
		Mondeo 2007>		190-5002330			22
		Ranger 2.5TD & 3.0TDCI 2007-2011		190-5002320			23
NEW	Ranger 2012>		190-5002160				
	S-max 2006>		190-5002330			22	
	Tourneo Connect 2007>		190-500233A			22	
	Transit 2006>		190-5002330			22	
	Transit Connect 2007>		190-500233A			22	

NEW	Brand	Type	Note	Plug and Play	Univerŝal harness	Remark	Photo
	Fiat	500		190-5002380			20
		Bravo <2011		190-5002110			2
		Bravo 2011>		190-5002130			3
		Croma 2005>		190-5002130			3
		Doblo I / Ram		190-5002110			2
		Doblo II 2009>		190-5002130			
		Ducato <2006		190-5002230			7
		Ducato 2006>		190-5002110			2
		Fiorino 2008>		190-5002110			2
		Grande Punto		190-5002130			3
		Idea		190-5002110			2
		Linea		190-5002130			
		Marea 1999>			190-500225W		
		Multipla 1998-2004		190-5002110			2
		Panda 2003>	for versions with electronic throttle pedal	190-5002380			20
		Punto 2003-2009		190-5002110			2
		Punto Evo 2009>		190-5002130			3
		Qubo		190-5002110			2
		Scudo <2007			190-500009A	cut connectors from the T-harness and solder to potentiometer harness	8
		Scudo 2007-2008		190-500017A			16
		Scudo MY2009		190-500041A			
		Sedici		190-5002210			13
		Stilo 2001>		190-5002110			2
		Strada		190-5002110			2
		Ulysse <2005			190-500009A	cut connectors from the T-harness and solder to potentiometer harness	8
		Ulysse 2.2 JTD 2006>		190-500017A			16
	GAZ	Gazelle Business		190-5002130			3
		Siber		190-5002360			
	Honda	Accord 2006-2008			190-500225W		14
		Accord 2008>		190-5002240			17
		Civic <2006			190-500225W		14
		Civic 2006>		190-5002240			17
		Civic Hybrid		190-5002240			17
		CRV 2007>		190-5002240			17
		CRV <2006			190-500225W		14
		Jazz 2002-2008			190-500225W		15
		Jazz 2009>			190-500225W		27
		Fit 2009>			190-500225W		27
		Insight 2009			190-500225W		27
		FRV			190-500225W		14
	Hyundai	Accent		190-5002110			2
		Elantra		190-5002100			4
		Getz <2007		190-5002100			4
update		Getz 2008> Left Hand Drive		190-5002400			2
update		Getz 2008> Right Hand Drive		190-5002110			2
		Grandeur		190-5002370			6
		H1 / i800 2.5 CRDI		190-5002110			2
		H200 CRDI		190-5002110			2
		H300 / Satellite		190-5002110			2
update		i10 CRDI		190-5002400			2
NEW		i40		190-5002370			
		Matrix <2007		190-5002100			4
		Matrix 2008>		190-5002110			2
		Santa-Fe petrol		190-5002100			
		Santa-Fe 2.0CRDI, 2.2CRDI 2006-2010		190-5002100			4
		Santa-Fe 2.7CRDI, 3.3CRDI 2006-2010		190-5002110			
		Santa-Fe 2.0CRDI 2010>		190-5002370			6
		Santa-Fe 2.2CRDI 2010>		190-5002460			3
		Sonata 2.0 CRDI		190-5002370			6
		Sonata 2.4		190-5002370			6
		Terracan 2.9 CRDI		190-5002110			2
		Terracan 2.9 CRDI		190-5002100			4
		Trajet		190-5002110			2
		Trajet		190-5002100			4
		Tucson	Not for 2.7 petrol 129KW	190-5002100			4
NEW		Veloster		190-5002460			3
	Iveco	Turbo Daily 2006>		190-5002110			2

NEW	Brand	Type	Note	Plug and Play	Univerſal harness	Remark	Photo
NEW	Jaguar	S-Type 1998-2004	requires canbus interface for speed signal		190-500225W		7
NEW		X-type 2001->	requires canbus interface for speed signal		190-500225W		7
	Jeep	Cherokee 2.8 CRD			190-500225W		
		Cherokee 2008-Compass		190-5002360			25
		Patriot		190-5002360			6
		Wrangler 2008>			190-500225W		6
							25
	Kia	Carens <2005		190-5002100			4
		Carens 2006>		190-5002370			6
		Carnival 2.9 CRDi		190-5002100			4
		Carnival 2.9 CRDi		190-5002110			2
update		Cee'd 2006> manual transmission		190-5002110			2
update		Cee'd 2006> automatic transmission		190-5002110			2
		Cerato		190-5002110			2
		Magentis 2006>		190-5002370			6
		Picanto <2007		190-5002100			4
update		Picanto 2008-2010		190-5002110			2
update		Picanto 2011>		190-5002400			2
		Pro-Ceed		190-5002110			2
		Rio <2007		190-5002110			2
		Rio 2007>		190-5002400			2
		Soul		190-5002400			2
		Soul 2010> diesel		190-5002110			2
		Sorento <2005		190-5002100			4
		Sorento 2006-2009		190-5002110			2
update		Sorento 2009> manual transmission		190-5002460		from 2011 onwards needs PULL-UP on speed signal	3
update		Sorento 2009 > automatic transmission		190-5002460		from 2011 onwards needs PULL-UP on speed signal	3
		Sportage CDRI (2004-2009)		190-5002110			2
		Sportage 2010>		190-5002370			6
		Venga		190-5002400			2
	Lancia	Delta 2008>		190-5002110			2
		Lybra 1.9 JTD		190-5002110			2
		Musa		190-5002110			2
		Ypsilon 2006>		190-5002380			20
update	Land Rover	Defender Td-4		190-5002510			
update		Defender Td-5		190-5002500			
		Discovery 2004>			190-500225W		
		Freelander (1997-2003)			190-500225W		
		Freelander Td-4 (2003-2006)		190-5002200			9
		Freelander 2 (2007>)		190-5002330			22
	Lexus	IS-200		190-5002210			
	Isuzu	D-max / Rodeo 2009>			190-5002480		
		I-Series 2009>			190-5002480		
		KB 2009>			190-5002480		
		T-series 2009>			190-5002480		
	LDV	Maxus		190-5002230			7
	Mahindra	Scorpio (GOA)		190-5002110			2
	Mazda	2 <2007		190-5002200			9
		2 petrol 2007-2010		190-5002220			11
		2 Diesel 2008-2010		190-5002330			22
		2 2011>		190-5002220			
		3 CITD, MPS, 2.0 petrol <2010		190-5002330			22
update		3 2011>	all models	190-5002190	190-500233W		
		5 CITD 2005-2010		190-5002210			13
		5 CITD 2011->	all models	190-5002330			22
		5 Petrol 2008->		190-5002330			22
		6 <2007		190-5002210			13
update		6 2008>		190-5002160	190-500225W		25
		B2500		190-5002320			23
		BT-50 2.5TDI & 3.0 CRDi		190-5002320			23
		CX7		190-5002220			11
		MPV		190-5002320			23
		MX5 2006>		190-5002210			13
		RX8		190-5002210			13

NEW	Brand	Type	Note	Plug and Play	Univerſal harness	Remark	Photo
	Mercedes	A Class		190-5002490	190-500225W		18
		B Class		190-5002490	190-500225W		18
		C-Class 2007>		190-5002440			21
		Sprinter <2006		190-5002490	190-500225W		18
		Sprinter 2006>		190-5002440			21
		Vaneo		190-5002490	190-500225W		18
update		Viano CDI		190-5002490	190-500225W		
		Vito <2006		190-5002490	190-500225W		18
		Vito 2006>		190-5002440			21
update	Mini	Mini 2001>		190-5002490	190-500225W		18
update	Mitsubishi	Canter 2008-2010	not for EURO-5 engines		190-500034W		
NEW		Canter 2010>	EURO-5 engines		190-500034X		
		Carisma DI-D 2001>		190-5002140			
		Colt (2005>)		190-5002130			3
		Grandis 2.0 DI-D			190-500225W		13
		Grandis 2.4 MPI			190-500225W		13
		Lancer 2008>		190-5002360			6
		L200 Model 2006		190-5002290			13
		Outlander 2007>		190-5002360			6
		Pajero <2006					
		Pajero 2006>		190-5002290			13
		Shogun 2006>		190-5002290			13
		Space Star		190-5002140			
	Nissan	Almera		190-5002130			3
		Almera Tino		190-5002130			3
		Altima 2007>		190-5002180			12
		Cabstar F24 2007>		190-5002180			12
		Cube		190-5002180			12
		Interstar		190-5002140			7
		Kubistar		190-5002140			7
		Maxima		190-5002180			12
		Maxity		190-5002180			
		Micra 2003>		190-5002180			12
		Murano 2008>		190-5002180			12
update		Navara 2005>		190-5002130		Speed pulse Navara 2011>: combi-instrument panel connector, pin no. 5 (no pull-up) !!	3
		Note		190-5002180			12
		NP300		190-5002130		190-5002120 (diesel)	12
		NV200 dci + Petrol		190-5002180			12
		Pathfinder		190-5002130			3
		Patrol 2007>		190-5002180			12
		Pixo		190-5002210			
		Primastar		190-5002140			7
		Primera		190-5002130			3
	QashQai 2007>		190-5002180			12	
	Teana		190-5002180			12	
	Tiida		190-5002180			12	
	X-trail 2004-2007		190-5002120			5	
	X-Trail 2007>		190-5002180			12	
	350Z		190-5002120			5	

NEW	Brand	Type	Note	Plug and Play	UniVëršal harness	Remark	Photo
	Opel	Aquila 2003-2007		190-5002130			3
		Aquila 2008>		190-5002210		Speed pulse. Manual gearbox: brown wire Power Steering module (blue) connector (behind mid-console, right side). Automatic gearbox: TCM 26-pole connector, pin 25 purple wire (A-style passenger side)	13
		Antara		190-5002390			20
		Astra G (1998-2004)			190-500225W		
		Astra H (2004-2009)		190-5002130			3
		Astra J (2009>)		190-5002130			3
		Combo 2006>		190-5002130			3
		Corsa 2006>		190-5002130			3
		Frontera			190-500225W		
		Meriva 2004-2010		190-5002130			3
		Meriva B (2010>)		190-5002390			20
		Movano A <2010		190-5002140			7
		Movano B 2010>		190-5002180			
		Tigra Twin-top		190-5002130			3
		Tour		190-5002130			3
		Vectra B		190-5002130			3
		Vectra C		190-5002130			3
		Vivaro 2006>		190-5002140			7
		Vivaro <2006		190-5002140			7
		Zafira <2005			190-500225W		
	Zafira 2005>		190-5002130			3	
	Peugeot	107 <2007		190-500009A			16
		107 Petrol 2008>		190-5002220			11
		1007 (2005-2006)		190-500009A			1
		1007 (2006>)		190-500017A			16
		206 (first generation)			190-500009A	cut connectors from the T-harness and solder to potentiometer harness	8
		206/SW/CC (2005-2006)		190-500009A			1
		206 2006>		190-500017A			16
		207 (2006-2008)		190-500017A			16
		207 2008>		190-500041A			26
		306 HDI			190-500009A	cut connectors from the T-harness and solder to potentiometer harness	8
		307 (first generation)			190-500009A	cut connectors from the T-harness and solder to potentiometer harness	8
		307/SW/CC (2005-2006)		190-500009A			1
		307 2006>		190-500017A			16
		308 <2008		190-500017A			16
		308 2009>		190-500041A			26
		3008		190-500041A			26
		406 HDI			190-500009A	cut connectors from the T-harness and solder to potentiometer harness	8
		407/SW/Coupe (2005-2006)		190-500009A			1
		407/SW/Coupe 2006>		190-500017A			16
		407 2008>		190-500041A			26
		4007		190-5002360			6
		5008		190-500041A			26
		806 HDI			190-500009A	cut connectors from the T-harness and solder to potentiometer harness	8
		807			190-500009A	cut connectors from the T-harness and solder to potentiometer harness	8
		807 2.0 2008>		190-500017A			16
		Bipper		190-5002110			2
		Boxer <2006		190-5000230			7
		Boxer 2006>		190-5002110			2
		Expert <2007			190-500009A	cut connectors from the T-harness and solder to potentiometer harness	8
		Expert 2008>		190-500041A			26
	Partner (2005-2006)			190-500009A	cut connectors from the T-harness and solder to potentiometer harness	8	
	Partner 2006-2008		190-500017A			16	
	Partner 2009>		190-500041A			26	
	Porsche	911/997 2004-2008		190-5002230			7
		911 2008>			190-500225W		
		966 MY2000			190-500225W		
		Boxster			190-500225W		
		Boxster S			190-500225W		
		Cayenne		190-5002230			7

NEW	Brand	Type	Note	Plug and Play	Univerſal harness	Remark	Photo
	Renault	Avantime		190-5002140			7
		Clio II 2001-2005		190-5002140			7
		Clio III 2005>		190-5002180			12
		Espace		190-5002140			7
NEW		Fluence		190-5002180			12
		Kangoo		190-5002140			7
		Kangoo 2008>		190-5002180			12
		Koleos		190-5002180			12
		Laguna 2001-2005		190-5002140			7
		Laguna 2006>		190-5002180			12
NEW		Laguna 2011>		190-5002150			12
		Master 2003-2010		190-5002140			7
		Master 2010>		190-5002180			12
		Maxity		190-5002180			12
		Mégane 03>		190-5002180			12
		Mégane 03> Automatic		190-5002180			12
		Modus / Grand Modus		190-5002180			12
		Scénic 08-2003>		190-5002180			12
		Trafic		190-5002140			7
		Twingo 1996-2007		190-5002140			7
		Twingo 1.2 16V 2007>		190-5002430			12
		Vel Satis		190-5002140			7
	Saab	9-3 2002>		190-5002130			3
	Seat	Alhambra		190-5002230			7
		Alhambra 1.9TDI	Adaptor harness need modification	190-5002310			7
		Altea 2004>>		190-5002450			10
		Arosa 2002-2004		190-5002230			7
		Arosa 1.4TDI 2002-2004	Adaptor harness need modification	190-5002310			7
		Cordoba		190-5002230			7
		Cordoba 1.4TDI		190-5002450			7
		Cordoba 1.9TDI	Adaptor harness need modification	190-5002310			7
		Exeo		190-5002450			7
		Ibiza 2002-2008		190-5002230			7
		Ibiza 1.4TDI, 1.9TDI 2002-2008	Adaptor harness need modification	190-5002310			7
		Ibiza 2008>		190-5002230			7
		Leon 2002-2006		190-5002230			7
		Leon 1.9TDI 2002-2006	Adaptor harness need modification	190-5002310			7
		Leon 2006>		190-5002450			10
		Toledo <2004		190-5002230			7
		Toledo 1.9 TDI <2004	Adaptor harness need modification	190-5002310			7
	Toledo 2004>		190-5002450			10	
	Skoda	Fabia 2000-2006		190-5002230			7
		Fabia 1.4TDI, 1.9TDI 2000-2006	Adaptor harness need modification	190-5002310			7
		Fabia 2006>		190-5002230			7
		Fabia 1.4TDI, 1.9TDI 2006>	Adaptor harness need modification	190-5002310			7
		Octavia <2004		190-5002230			7
		Octavia 1.9TDI <2004	Adaptor harness need modification	190-5002310			7
		Octavia 2004>		190-5002450			10
		Roomster		190-5002230			7
		Roomster 1.4TDI, 1.9TDI	Adaptor harness need modification	190-5002310			7
		Superb		190-5002450			10
	Yeti		190-5002450			10	
	Smart	ForFour		190-5002130			3
		ForTwo <2007			190-500225W		2
		ForTwo 2007>		190-5002440			21
	Ssang Yong	Actyon A200 Xdi		190-5002110			2
		Actyon A230		190-5002110			2
		Kyron M200Xdi		190-5002110			2
		Rexton 2006>		190-5002110			2
		Rexton 230			190-500225W		18
		Rexton 270		190-5002110			2
	Rodius 270		190-5002110			2	

NEW	Brand	Type	Note	Plug and Play	Univerſal harness	Remark	Photo	
	Subaru	Forester 2.0		190-5002220			11	
		Forester 2008>		190-5002220			11	
		Impreza 2005>		190-5002220			11	
		Legacy 2003>			190-500225W		13	
		Outback						
		Tribeca						
NEW		Trezia		190-5002280			28	
		WRX STI						
	Suzuki	Alto 2009>		190-5002210			13	
		Alto 1.0 Automatic		190-5002210			13	
		Grand Vitara <2006			190-500050W		8	
		Grand Vitara 2006>		190-5002210		for speed pulse input use brown wire from the power steering module (blue) connector (behind mid-console, right side)	13	
		Ignis 1.3 Diesel		190-5002130			3	
		Jimny 1.5 DSL		190-5002460			3	
		Liana			190-500050W		8	
		Splash		190-5002210		for speed pulse input use brown wire from the power steering module (blue) connector (behind mid-console, right side)	13	
		Swift Diesel 2005-2008		190-5002130			3	
		Swift Diesel 2008>		190-5002210		for speed pulse input use brown wire from the power steering module (blue) connector (behind mid-console, right side)	13	
		Swift Petrol 2005-2008		190-5002210			13	
		Swift Petrol 2008>		190-5002210		for speed pulse input use brown wire from the power steering module (blue) connector (behind mid-console, right side)	13	
		SX4 1.6		190-5002210			13	
update		Wagon R 1.3 DDIS 51KW		190-5002130			3	
	Toyota	Avensis < 2008		190-5002120			5	
		Avensis Verso < 2008		190-5002120			5	
		Avensis 2009 >		190-5002220			11	
		Aygo <2007		190-500009A			1	
		Aygo MMT 2006-2007		190-5002220			11	
		Aygo Petrol 2008>		190-5002220			11	
		Auris 2007>		190-5002220			11	
		Camry 2001-2005		190-5002120			5	
		Corolla <2007		190-5002120			5	
		Corolla 2007>		190-5002220			11	
		Corolla Verso		190-5002120			5	
		Hi-ace		190-5002120			5	
		Hi-lux <2005		190-5002120			5	
		Hi-lux 2005>		190-5002210			13	
		IQ		190-5002220			11	
		Land Cruiser 90		190-5002120			5	
		Land Cruiser 100 2005>		190-5002210			13	
		Land Cruiser 120 2003>		190-5002210			13	
		Land Cruiser 150 Prado 2005-2009		190-5002210			13	
		Land Cruiser 150 Prado 2009>	manual gearbox	190-5002220			11	
		Prius 2011>		190-5002220			11	
		Prius 2005-2010		190-5002210			13	
		Prius 2001-2004		190-5002120			5	
		Previa 2000>		190-5002120			5	
		Raider		190-5002210			13	
		RAV4 <2006		190-5002120			5	
		RAV4 2006>		190-5002220			11	
		Sienna 2003>		190-5002210			13	
		Urban Cruiser		190-5002220			11	
		Verso		190-5002220			11	
update			Verso S		190-5002280			28
			Yaris D4D <2006		190-5002120			5
		Yaris 2006-2011		190-5002220		mount Clutch Switch	11	
		Yaris 1.0 (MMT) 2006>		190-5002220			11	
NEW		Yaris MY-2012		190-5002280			28	

NEW	Brand	Type	Note	Plug and Play	Univerŝal harness	Remark	Photo
	UAZ	Cargo		190-5002110			2
		Patriot		190-5002110			2
		Pickup		190-5002110			2
	Volkswagen	Amarok		190-5002450			10
		Beetle		190-5002450			10
		Bora		190-5002230			7
		Bora 1.9TDI		190-5002310			7
		Caddy 2004>		190-5002450			10
		Caravelle		190-5002230			7
		Caravelle 1.9 & 2.5 TDI		190-5002310			7
		Crafter 06>		190-5002440			21
		EOS		190-5002450			10
		Fox 1.2, 1.4 2005>		190-5002230			7
		Golf 4		190-5002230			7
		Golf 4 1.9TDI <2003		190-5002310			7
		Golf 5 (Plus) 2003>		190-5002450			10
		Golf 6		190-5002450			10
		Jetta 2005>		190-5002450			10
		Multivan 2003-2009	Use AP900C for 2009> models!	190-5002230			7
		Multivan 1.9 & 2.5 TDI 2003-2009	Use AP900C for 2009> models!	190-5002310			7
		Passat 2000-2005		190-5002230			7
		Passat 1.9&2.5 TDI <2005		190-5002310			7
		Passat 2005>		190-5002450			10
		Polo 1.4TDI, 1.9TDI 2002>		190-5002310			7
		Polo 1.2TDI 2002>		190-5002230			10
		Polo Petrol 2002>		190-5002230			10
		Lupo		190-5002230			7
		Lupo 1.4TDI & 3L 1.2TDI		190-5002310			7
		Scirocco 2008>		190-5002450			10
		Sharan 2000>		190-5002230			7
	Sharan 1.9TDI 2000>		190-5002310			7	
	Sharan 2.0 TDI 2000>		190-5002450			7	
	Tiguan		190-5002450			10	
	Touareg 2002>		190-5002230			7	
	Touran 2003-2006		190-5002230			7	
	Touran 1.9TDI 2003-2006		190-5002310			7	
	Touran 2006>		190-5002450			10	
	Transporter 5 2003-2009	Use AP900C for 2009> models!	190-5002230			7	
	Transporter 5 1.9 & 2.5 TDI		190-5002310			7	
	Volvo	C30		190-5002330	2008>		22
		S40		190-5002330			22
		V50		190-5002330			22
		C70		190-5002330			22
		V70 2007>		190-5002330			22
		XC70 2007>		190-5002330			22
		S80 2006>		190-5002330			22